



ET Trasformatore toroidale – Potenza da 60 a 600VA

- A=Ingresso cavi di alimentazione
- B=Fori fissaggio a parete
- C=Bloccaggio cavi in ingresso
- D=Morsetto di alimentazione
- E=Morsetto di uscita
- F=Serracavo uscita
- G=Fori per viti fissaggio coperchio
- H=Tappi copertura viti

ATTENZIONE! Prima di inserire sul coperchio i tappi H, accertarsi della corretta esecuzione del montaggio.

ET Transformateur toroidal – Puissance de 60 à 600VA

- A=Entrée des câbles d'alimentation
- B=Trous puour montage au mur
- C=Appareil de fixation des cables en entrée
- D=Borne d'alimentation
- E=Borne de sortie
- F=Serre-câble de sortie
- G=Trous pour vis de fixation du couvercle
- H=Bouchons pour la couverture des vis

ATTENTION! Avant d'insérer les bouchons H sur le couvercle, assurez-vous du correct montage.

ET Toroidal transformers – Power from 60 to 600VA

- A=Entry hole of supply cables
- B=Fixing holes for wall mounting
- C=Fixing device for input cables
- D=Power supply connector
- E=Output connector
- F=Output cable clamp
- G=Holes for lid fixing screws
- H=Screw cover caps

CAUTION! Make sure of the correct mounting of the device before inserting the H caps on the cover.